


Maintenance Guide

Retailer 2023

FOR HINGES AND GLASS MOUNTING BRACKETS

Regular maintenance of your screen hinges and fittings is necessary to keep them functioning smoothly. Every 3–6 months:

- Check that all screws on the hinges and glass mounting brackets are firmly secured; tighten any loose screws.
- Clean any dirt build-up with warm water and a small amount of dishwashing liquid. Rinse well and pat dry with a clean cloth.
- Use a few drops of machine oil to lubricate the moving parts of the hinges.

CLEANING & CARING FOR YOUR SHOWER SCREEN

Note: Wiping the glass dry with a microfiber cloth and/or using a squeegee after showering will help limit scum build-up on the glass and reduce the need for heavier cleaning.

- When cleaning your shower screen, only use products specifically designed for shower screens and follow the product instructions for best results.
- Alternatively, you can make an effective cleaner by mixing 1 part white vinegar to 10 parts water. Spray or sponge the vinegar mixture on the glass, then wipe and buff dry with a soft, lint-free cloth.

IMPORTANT


- Failure to follow the care and maintenance instructions on this page may void all warranties.

• Do not use blades, metal scrapers, abrasive cloths/sponges, steel wool, or abrasive or acid cleaners on any part of your shower screen.

• Do not allow cleaning agents or liquids, including water, to remain in contact with the glass or frames for long periods.

Covey Australia Pty Ltd

Marketing Team



Australia

PRODUCTS

Shower screen

Accessories

Nano Coating

Support Documents

SERVICES

Purchase guide

Maintenance guide

Warranty & Disclaimer

Return Policy

CONTACT

Sydney Headquarters:
Address: 36 Amax Avenue, Girraween 2145
Landline: 02 8677 6007
Email: Sales@ozcovey.com.au

Brisbane Branch
Address: 14 Annie St, Coopers Plains, QLD 4018
Email: Salesqld@ozcovey.com.au

Covey Australia Right Reserves @ 2025